User manual

ShishaX VOLTA · Electric shisha head · Model Black

This manual was prepared by HOOKAIN GmbH based on information from the manufacturer ShishaX (SHX Corporation). Read it completely before first use, especially the chapter “Safety and battery information”, and keep it for future reference. The notes on the device and on the packaging also apply. If you pass the device on, include this manual.

Contents

1	Overview	1
2	Parts overview	2
3	Package contents	3
4	Before first use	4
5	Filling the ceramic chamber	4
6	Assembling and placing on the shisha	4
7	Buttons and display	5
8	A session step by step	6
9	Temperature guide values	7
10	Charging, battery and pass-through	7
11	ShishaX app (optional)	8
12	Cleaning and care	8
13	Storage	9
14	Troubleshooting	9
15	Safety and battery information	10
16	Disposal	11
17	Warranty and registration	11
18	Technical data	13
19	Manufacturer and contact	13



1 Overview

The ShishaX VOLTA is an electric shisha head. It replaces both the head and the charcoal: you place it on the bowl adapter of the stem like a regular head, fill normal shisha tobacco into a ceramic chamber, and two electric heating zones provide the heat – the cap from above (radiant heat) and the chamber wall from the side (contact heat). You set both zones separately.

Power comes from a removable battery. You charge it via USB-C inside the device or on its own, and the device keeps running on the cable (pass-through). You operate it with the colour display and three buttons; the ShishaX app is optional.

Intended use

Use only as a heat source for normal shisha tobacco on a shisha (water pipe), with the original ShishaX ceramic chambers and metal screens. Do not use it for other substances, as a heater or cooker, or for any other purpose. For adults only. Tobacco is not included.

At a glance

Tobacco	approx. 10 g per fill
Heating	2 zones, top and side, set separately
Preheating	approx. 8 minutes, can be skipped
Session	duration adjustable, +10 minutes per double tap, 150 minutes maximum
Battery	removable battery 5,000 mAh, around 1 to 1.5 hours per charge (depending on temperature)
Charging	USB-C, approx. 1 to 1.5 hours; pass-through with the battery inserted
Connection	silicone grommets 18 mm and 16 mm
App	optional (ShishaX app, account required)

2 Parts overview



No.	Part	Function
1	Cap	Screws onto the heating chamber, closes it and holds the ceramic chamber. Upper heating zone (radiant heat).
2	Heating chamber with ceramic chamber	Holds the filled ceramic chamber. The chamber wall is the side heating zone (contact heat).
3	Display	Colour display (OLED according to the manufacturer): session time, cap and side temperature, battery level, connections, menus.
4	Buttons `<` `O` `>`	`<` and `>`: set temperatures, scroll through menus. `O`: on/off, heating, session duration, LED ring, button lock.
5	LED ring	Lighting with 5 modes, can be switched off.
6	Removable battery	Sits in the lower part and is held by the base cap; has its own USB-C port. The airflow channel to the shisha runs through the battery module.
7	Base cap	Screws on at the bottom and holds the battery. The silicone grommet goes into its opening.



A USB-C port on the lower part: charging in the device and pass-through



B Base cap unscrewed, battery pulled out



C Silicone grommet in the base cap, on the bowl adapter



D Heating zones: cap on top, side heating around the ceramic chamber (illustration)

Illustrations may differ from the product.

3 Package contents

- ShishaX VOLTA (device)
- 1 removable battery (inserted; remove the insulating sheet before first use, see chapter 4)
- 2 ceramic chambers
- 10 metal screens (5 upper, 5 lower)
- USB-C charging cable
- Silicone grommets 16 mm and 18 mm
- Cleaning and tool set: tweezers, metal brush, stem brush, hose brush, fork and spoon
- 4 single-use hygiene mouthpieces
- Velvet pouch
- User manual in German

Package contents as stated by the manufacturer; a USB-C charger is not included (suitable chargers: see “Charging, battery and pass-through”). After unpacking, check that everything is complete and undamaged. Do not use a damaged device – contact us instead.

4 Before first use

When delivered, an insulating sheet (transport protection) sits between the battery and the device. Remove it once before using the ShishaX VOLTA for the first time.

1. Unscrew the base cap on the underside.
2. Pull out the removable battery.
3. Peel off the insulating sheet between the battery contacts and the device.
4. Reinsert the battery.
5. Screw the base cap back on and tighten it firmly. If it is not fully screwed on, the device can come apart during use.
6. Fully charge the battery via USB-C before the first session (chapter 10).



5 Filling the ceramic chamber

You need one ceramic chamber, one lower and one upper metal screen and approx. 10 g of shisha tobacco.

1. Place a lower screen on the bottom of the ceramic chamber.
2. Put approx. 10 g of shisha tobacco on the screen.
3. Fluff up the tobacco with your fingers or a tobacco fork. It should sit loosely, not pressed down.
4. Place an upper screen on top.
5. Wipe the chamber rim clean with a cloth; no tobacco should remain on the rim.



Ceramic chamber



Placing the screen

Tip: Approx. 10 g works best. With less tobacco the fill is used up faster; with more, the upper screen sits too close to the heat. Weigh the amount for the first few times.

6 Assembling and placing on the shisha

Assembling the heating section

1. Place the filled ceramic chamber into the heating chamber with the screens facing up.
2. Screw on the cap until it sits firmly. Do not overtighten.

Choosing the right silicone grommet

- **18 mm:** fits most shishas (standard stems).
- **16 mm:** for thinner bowl adapters, or if the 18 mm grommet sits loosely or does not seal.

Placing on the shisha

1. Insert the silicone grommet into the opening of the base cap.
2. Lower the device onto the bowl adapter of the stem, grommet first.
3. Press down firmly until the grommet seals – you will feel resistance.
4. Seal test: cover the top of the device with your hand and draw on the hose. If you feel resistance, everything is sealed. If air flows freely, reseat the grommet or use the other size.



Placing on the bowl adapter



Grommet on the bowl adapter

- You do not need an additional head, charcoal, foil or an HMD; an HMD cannot be combined with the ShishaX VOLTA.
- Fill the base with clear water only, so that the downstem is just immersed. No ice slush and no viscous additives.
- The shisha must stand securely on a level, heat-resistant surface.
- With unusual or older bowl adapters, check before the first session that one of the two grommets seals tightly.

7 Buttons and display

There are three buttons below the display: **<** (left), **O** (centre, on/off) and **>** (right). The device saves changes automatically when you do not press a button for a few seconds; the display then returns to the home screen.

The device and the app display English texts; they are shown here in quotation marks exactly as they appear.



Display and buttons

What you want to do	How to do it
Switch on / off	press **O** once, then immediately press it again and hold until the display turns on or off
Set session duration	1× **O**, then adjust with **<** / **>**
Cap temperature (top)	1× **<**, then adjust with **<** / **>**
Side temperature	1× **>**, then adjust with **<** / **>**
Start preheating	2× **O** (double tap) on the home screen
Skip preheating	hold **O** for 2 seconds during preheating
Pause	1× **O** during the session
Resume	2× **O** after a pause
Extend session	2× **O** during the session: +10 minutes each, 150 minutes maximum in total
Set LED ring	3× **O**, then choose one of the 5 modes or “OFF” with **<** / **>**
Button lock on/off	4× **O** in quick succession
Device settings	**<** and **>** together; select with **<** / **>**, switch on or off with **O**

The display

- **Status bar:** time (24 h), Bluetooth, Wi-Fi, brightness and battery level in percent.
- **Home screen:** “PRESET” with the current preset (factory setting “Custom”), time circle with the session duration, temperature circle with cap and side temperature and a status line, e.g. “Start your session”.
- **“Pre-heating…”** – the device is preheating; the time circle shows a blue countdown, next to it the current temperature.
- **“Enjoy your session”** – the session is running.
- **“Paused”** – pause, both heating zones are off.
- **“Screen Locked”** – the button lock is active.
- **“OTA In Progress”** – a firmware update is running.

LED ring

3× **O** opens “LED Setting”. Use **<** / **>** to choose one of the 5 modes or “OFF”. With “OFF” the lighting is off; the device keeps working normally.

Button lock

4× **O** locks the buttons, 4× **O** again unlocks them. While locked, the device ignores all other buttons. A running session keeps heating, Bluetooth and Wi-Fi stay active. Useful when the shisha is passed around.

Device settings (Device Settings)

Press **<** and **>** at the same time. Select with **<** / **>**, switch on or off with **O**. The menu closes after a few seconds without input.

- **Wi-Fi:** Wi-Fi on/off – needed for firmware updates and app functions via Wi-Fi.
- **Bluetooth:** on/off – needed for pairing with the app.
- **Audio:** button and alert sounds on/off.
- **Screensaver:** screensaver on/off.
- **OTA Firmware:** start a firmware update (Wi-Fi only, chapter 11).

8 A session step by step

Switching on and off

Press **O** once, then immediately press it again and hold until the display turns on. Switching off works the same way until the display goes dark. If nothing happens, the battery is too low: charge for at least 30 minutes, then try again.

Tip: Charge the battery as fully as possible before each session, at least to 50 %. Below that the device may switch off during the session.

Setting the session duration

On the home screen press 1× **O**: the display shows “Time”. Set the duration in minutes with **<** / **>**. Wait a few seconds – the device saves the setting.

Setting the temperatures

1× **<** opens “Cap Temperature” (cap, top), 1× **>** opens “Side Temperature” (side). Change each with **<** / **>** and wait a few seconds. When you set values on the device, the preset “Custom” applies: one stage with fixed temperatures for the whole session. You create multi-stage profiles in the app. Guide values are in chapter 9.

Preheating

On the home screen press 2× **O** (double tap): the device preheats for approx. 8 minutes, the display shows “Pre-heating…” with a blue countdown. To skip: hold **O** for 2 seconds during preheating, e.g. when the chamber is still warm from the previous session.

During the session

- “Enjoy your session”: the device holds the cap and side temperature for the set duration.
- **Pause:** 1× **O**. The display shows “Paused”, both heating zones are off and the chamber cools down.
- **Resume:** 2× **O**. The device heats back up to the set values.
- **Extend:** 2× **O** during the session, +10 minutes per double tap, 150 minutes maximum in total.
- **Button lock:** 4× **O** (see chapter 7).

After the session

Switch the device off and let it cool for at least 30 minutes. The cap and heating chamber stay hot for a long time, even when the display is dark. Only then remove the ceramic chamber, and only with tweezers.

9 Temperature guide values

Guide values based on the manufacturer’s recommendation, not fixed rules. Change settings in small steps and wait a few minutes after each change before drawing again. The setting range is listed in the technical data (chapter 18).

Tobacco	Guide value
Starting point, most tobaccos	both zones 200 °C
Dark leaf	approx. 200–240 °C
Blonde leaf	approx. 180–220 °C

What you notice	Adjustment
Burnt or harsh at the top	lower the cap temperature (`<`) in steps of 10–20 °C
Burnt at the edge	lower the side temperature (`>`) in steps of 10–20 °C
Weak from the start	raise both zones by approx. 20 °C
Good at first, weak towards the end	raise the side temperature

More cap heat tends to suit denser fills and dark leaf; more side heat tends to suit looser fills, blonde leaf and long sessions.

10 Charging, battery and pass-through

Charging in the device

Connect the USB-C cable to the port on the lower part of the device and the other end to a USB-C power adapter. Charging power up to 24 W. The display shows the battery level and charging status.

Charging the battery externally

Unscrew the base cap, pull out the battery and connect the USB-C cable directly to the port on the battery. Charging power up to 36 W, so faster. Then insert the battery and screw the base cap on firmly.

Power adapter, cable and charging time

Suitable are USB-C power adapters with 5 V/5 A, 9 V/3 A or 12 V/3 A. A full charge takes approx. 1 to 1.5 hours; weaker adapters charge more slowly. Use the supplied cable or a high-quality USB-C cable – a weak cable can interrupt the session.

Running time

One battery charge lasts around 1 to 1.5 hours, depending on the temperature. For longer sessions use pass-through or a second ShishaX VOLTA battery.

Pass-through

If you connect the USB-C cable to the lower part during the session, the device keeps running on the cable; surplus power charges the battery. Pass-through only works with the battery inserted.

Changing the battery

Between two sessions: switch the device off, unscrew the base cap, pull out the battery, insert a charged battery and screw the base cap on firmly.

- Charge at room temperature, not in direct sunlight, not in frost and not near heat sources.
- Do not regularly run the battery completely flat; it is better to recharge fully after a session.
- Charge on a non-flammable surface and never unattended (chapter 15).

11 ShishaX app (optional)

The ShishaX VOLTA can be operated completely with the display and buttons. The ShishaX app is optional. It offers up to 10 presets (multi-stage heating profiles), remote preheating, live values, LED settings and firmware updates. The app requires a ShishaX account.

Android
Install the ShishaX app from Google Play.
https://play.google.com/store/apps/details?id=com.shishax.app

iPhone / iPad
Install the browser “SHX Browser” from the App Store and open the web app **shishax.app** in it. There is no separate iOS app.
https://apps.apple.com/app/id6763203301

Pairing the device

1. Install the app (iPhone: SHX Browser, open https://shishax.app in it) and create a ShishaX account (“Register”) or sign in (“Login”).
2. Switch on Bluetooth on the device: **<** + **>** together, select “Bluetooth”, press **O**.
3. Switch on Bluetooth on your phone. Android asks for location permission; it is required for the Bluetooth scan.
4. In the app tap “Launch” and select the device “VOLTA_xxxx”. Stay close by (about 2 m); the device must not be locked.
5. If the app offers a firmware update, follow the instructions.

Wi-Fi (optional)

The ShishaX VOLTA only connects to 2.4 GHz networks, not to 5 GHz. On the device press **<** + **>** together, select “Wi-Fi”, press **O**. In the app under “Device Settings” → “Wi-Fi” enter the network name and password (case-sensitive) and tap “Connect”. Your phone should be on the same 2.4 GHz network.

Firmware update

Via Wi-Fi: **<** + **>** together, select “OTA Firmware”, press **O** (only active when an update is available). The battery should be charged above 50 %. Do not press any button during the update; the device restarts by itself afterwards.

12 Cleaning and care

Caution: Only clean the device when it is switched off and has cooled for at least 30 minutes. The device is not waterproof: never rinse it, never immerse it in water or cleaning agents, never put it in the dishwasher.

After every session

1. Switch the device off and let it cool for at least 30 minutes.
2. Unscrew the cap.
3. Remove the ceramic chamber with tweezers, not with your fingers.
4. Dispose of the tobacco residue and remove the screens. Replace heavily clogged screens; rinse the others and let them dry completely.
5. Carefully brush out the inside of the heating chamber with a metal brush.
6. Wipe the cap with a dry cloth.
7. Only reassemble when all parts are completely dry.

Deep cleaning (weekly with daily use, otherwise every few sessions)

1. Switch the device off and let it cool for at least 30 minutes.
2. Unscrew the cap, remove the ceramic chamber with tweezers, take out the screens.
3. Unscrew the base cap, remove the battery and put it down somewhere dry.
4. Clean the heating chamber with the metal brush in slow circles. Do not scrape the heating elements.
5. Pull a long, thin channel brush through the airflow channel from both ends until it comes out clean.
6. Wipe the cap and ceramic chamber dry; carefully loosen stubborn residue on the chamber with the metal brush.
7. Reinsert the battery, base cap, ceramic chamber and cap, all firmly seated. Take the opportunity to clean the shisha hose with a hose brush.

What damages the device

- Rinsing, immersing or the dishwasher; dripping wet cloths on the heating chamber or charging port
- Steel wool, scouring pads, bleach or ammonia cleaners, acetone, solvents, oven cleaner
- Cleaning while the device is hot; deep cleaning with the battery inserted

Clean the charging port only with a dry cotton swab. If any of this has happened, stop using the device and contact us or ShishaX support.

Normal: discoloration of the ceramic chamber does not affect its function, and sticky residue on the chamber rim builds up slowly. Replace a ceramic chamber when it has cracks.

13 Storage

- Store upright, clean, dry and out of the reach of children; do not store upside down for long periods.
- Longer break (a few weeks or more): charge the battery to approx. 50 %, not full, and store the device and battery in a cool, dry place.
- Avoid temperatures below 0 °C and above 40 °C, e.g. not in a hot car or on radiators.
- For long-term storage, recharge the battery to approx. 50 % every 2 to 3 months.

14 Troubleshooting

Problem	Possible cause	Remedy
Device does not switch on, display stays dark	Insulating sheet still in place (first use); battery empty or in protection mode	Remove the insulating sheet (chapter 4). Charge for at least 30 minutes – the display may stay dark meanwhile – then switch on.
Buttons do not respond	Button lock active; battery empty	Press **O** 4× in quick succession; otherwise charge for at least 30 minutes.
No smoke when drawing	Device off or locked; air holes in the chamber bottom blocked by tobacco	Switch on or unlock. Otherwise let it cool (30 minutes), remove cap and chamber, clean the air holes and chamber bottom.
Device heats, but no smoke	Blockage in the smoke path; tobacco packed too tightly; grommet not sealing; too much water in the base	Let it cool, take it apart, clean the airflow channel, heating chamber and hose. Fill loosely. Reseat the grommet or use the other size. Water only so high that the downstem is just immersed.

Problem	Possible cause	Remedy
Burnt taste	Temperature too high; tobacco on the chamber rim	Lower the affected zone in steps of 10–20 °C (chapter 9); wipe the chamber rim clean.
Taste too weak	Temperature too low	Raise both zones by approx. 20 °C; if it fades towards the end, raise the side temperature.
Draw too tight	Air holes blocked; tobacco packed too tightly; ice or viscous additives in the water	Clear the air holes with the metal brush; fill more loosely; use fresh, clear water.
Draw too loose	Hose or mouthpiece not tight; leak at the shisha; grommet too small or worn	Check all shisha connections; use the other grommet.
Liquid on the device	Condensate (normal in small amounts); device tilted; strong temperature change; grommet damaged	Use and store upright, wipe dry. Check the grommet and use the second grommet if it is cracked.
Does not charge	Dirt in the charging port; cable or adapter faulty; battery deeply discharged	Clean the port with a dry cotton swab; try another cable and adapter; leave connected for at least 30 minutes.
App does not find the device	Bluetooth off; device locked; too far away	Switch on Bluetooth on device and phone, unlock, move closer (about 2 m), restart the app.
Wi-Fi does not connect	5 GHz network; wrong network name or password	Choose a 2.4 GHz network; check entries carefully (case-sensitive).
Smell of burnt plastic or metal	possible defect	Switch off immediately, unplug the cable, stop using it, contact support.

If this does not help, contact us or ShishaX support: support.shishax.com/ticket.

15 Safety and battery information

Read this information before first use and follow it. It protects against burns, fire, electric shock and damage to the device.

General

- For adults only. Use and store the device, battery and accessories out of the reach of children and pets.
- Use only as intended: as a heat source for normal shisha tobacco on a shisha, with original ceramic chambers and screens.
- Before each use, check the housing, cap, grommet, battery and cable for damage. Do not use a damaged device.
- Do not open, modify or repair the device or battery yourself.

Heat and fire hazard

- The cap, heating chamber and ceramic chamber become very hot and stay hot for a long time after the session, even when the display is dark. Do not touch. Only remove the ceramic chamber after cooling and only with tweezers.
- Place the shisha on a stable, level, heat-resistant surface, away from flammable objects such as curtains, paper or textiles. Do not cover the device.
- Do not tilt, turn over or carry the device around during use, and never operate it unattended.
- Before first use, remove the insulating sheet between the battery and the device and then screw the base cap on firmly.
- If you smell burnt plastic or metal, if smoke comes out of the housing or if it becomes unusually hot: switch off immediately, unplug the cable, let it cool and stop using it.
- Make sure the room is adequately ventilated.

Water and cleaning

- The device is not waterproof: never rinse it, never immerse it in water or cleaning agents, never put it in the dishwasher. Do not let liquid get into the heating chamber or ports.
- Before each cleaning, switch off and let it cool for at least 30 minutes; remove the battery before deep cleaning.
- Do not operate, connect or charge with wet hands.

Battery (lithium-ion)

- Only use original ShishaX batteries for the ShishaX VOLTA.
- Only charge with suitable USB-C power adapters (5 V/5 A, 9 V/3 A or 12 V/3 A) and an undamaged cable. Charge on a non-flammable surface, at room temperature and never unattended, not overnight.
- Do not charge or store near heat sources, in direct sunlight or in a hot car; storage temperature 0–40 °C.
- Do not open, crush, puncture, drop, short-circuit, throw into fire or let the battery get wet. Keep the contacts away from metal objects such as keys or coins; only transport a loose battery with covered contacts.
- Do not charge or use a damaged, deformed, swollen, unusually hot or smelling battery any more. Place it on a non-flammable surface, let it cool and hand it in at a collection point.
- If liquid leaks from the battery, avoid contact with skin and eyes; in case of contact rinse thoroughly with water and seek medical advice.
- When travelling by air, follow the airline’s rules for lithium-ion batteries (battery data: 10.95 V, 5,000 mAh, 54.75 Wh, according to the manufacturer).

Radio

- The device uses Bluetooth and Wi-Fi (2.4 GHz). Where radio use is prohibited, switch off Bluetooth and Wi-Fi in the device settings.

16 Disposal



- The crossed-out wheeled bin symbol means: waste electrical and electronic equipment must not be disposed of with household waste. Take the device to a municipal collection point or a retailer’s take-back point.
- Remove the battery first (unscrew the base cap) and dispose of it separately: waste batteries do not belong in household waste. Return is free of charge at retailers and municipal collection points. Cover the contacts with tape beforehand; hand in a damaged battery separately.
- Personal data: remove the device from your ShishaX account before handing it in (app: “Home” → bin icon next to the device). You are responsible for deleting personal data.
- Dispose of ceramic chambers with residual waste, metal screens with metal or recycling collection, and packaging with paper and packaging collection.

Legal basis: WEEE Directive 2012/19/EU and Battery Regulation (EU) 2023/1542, as implemented in your country. Follow your local rules.

17 Warranty and registration

Manufacturer’s warranty: ShishaX grants a warranty of 1 year on the device and 6 months on the removable battery, each from the date of purchase. This is a voluntary commitment by ShishaX; it only applies if you register your device in the manufacturer’s portal.

Statutory warranty: Your statutory warranty rights against us as the seller remain unaffected and also apply without registration.

How to register your device

1. Note down the serial number. It is on the underside of the device or on the original packaging; with the app also under “Device Settings” → “Device Info” → “Serial number”.
2. Have your invoice or order confirmation ready as a photo or PDF.
3. Open portal.shishax.eu and tap “Continue with ShishaX account”. If you do not have a ShishaX account, create one first.
4. In the “Warranty” menu tap “+ Register Device”.
5. Fill in the form: “Product Name” (VOLTA), “Serial Number”, “Purchase Date” (invoice date), under “Purchased From?” select “Other”; “Receipt Image” (upload your invoice), name, address, “Country”, “State” (region), postcode; phone is optional.
6. Tap “Submit”. ShishaX checks the details within 1–2 working days; the portal then shows the status.

Warranty portal
portal.shishax.eu

Tip: Register right after purchase. Without registration, ShishaX cannot verify the start of the warranty or process a warranty claim.

Not covered by the manufacturer’s warranty

Ceramic chambers, screens, brushes and tools (wear parts); damage from drops, water and cleaning; damage from third-party batteries or chargers; modifications and repair attempts; improper use, including with substances other than shisha tobacco.

Reporting a warranty claim

Open a ticket at support.shishax.com/ticket, category “Device / Warranty”, subject containing “Warranty claim”. Attach: invoice or order number, a short description of the fault, photos or a video. ShishaX replies within 1–2 working days and, if the claim is accepted, sends return instructions; repair or replacement usually takes 5–10 working days after receipt. You can follow the status in the portal under “RMA”. You can also contact us at any time.

18 Technical data

Brand / model	ShishaX VOLTA, colour Black
Product type	Electric shisha head (replaces head and charcoal)
Heating	Two separately adjustable heating zones: top (cap, radiant heat) and side (chamber wall, contact heat)
Setting range top	50–360 °C (according to the manufacturer)
Setting range side	100–250 °C (according to the manufacturer)
Tobacco	approx. 10 g per fill, between lower and upper metal screen
Preheating	approx. 8 minutes, can be skipped
Session duration	adjustable on the device, +10 minutes per double tap, 150 minutes maximum
Battery	Removable battery Li-ion 21700-3S1P, 10.95 V, 5,000 mAh, 54.75 Wh (according to the manufacturer)
Running time	around 1 to 1.5 hours per battery charge, depending on temperature (according to the manufacturer)
Charging	USB-C (5 V/5 A, 9 V/3 A, 12 V/3 A); in the device up to 24 W, battery externally up to 36 W
Charging time	approx. 1 to 1.5 hours (according to the manufacturer; longer with basic adapters)
Pass-through	yes, with the battery inserted
Operation	Colour display (OLED according to the manufacturer), three buttons, button lock
Lighting	LED ring, 5 modes, can be switched off
Connectivity	Bluetooth, Wi-Fi (2.4 GHz only); firmware updates via Wi-Fi
App	optional; ShishaX app (Android), iPhone via SHX Browser and shishax.app; ShishaX account required; up to 10 presets
Connection to the shisha	Silicone grommets 18 mm and 16 mm for the bowl adapter
Manufacturer’s warranty	Device 1 year, battery 6 months, from the date of purchase, after registration at portal.shishax.eu

19 Manufacturer and contact

Manufacturer

ShishaX · SHX Corporation · 1602 Lockness Place · Torrance, CA 90501 · USA
Phone: +1 908 947 8590 · E-mail: sales@shishax.com · shishax.com · Support: support.shishax.com

Retailer

HOOKAIN GmbH · Grüner Brunnenweg 146 · 50827 Köln · Germany
Phone: +49 221 999 88 111 · E-mail: b2b@hookain-tobacco.com

Status: 27.09.2026, version 1. Information according to the manufacturer; illustrations may differ from the product. Tobacco is not included.