Quick start guide

ShishaX VOLTA · Electric shisha head · Model Black

The detailed user manual with all safety information is available via the QR code on page 2. Read the safety information before first use.



1 Remove insulating sheet

Unscrew the base cap, pull out the battery, peel off the insulating sheet, insert the battery, screw the base cap on firmly (first time only).



2 Charge the battery

Connect the USB-C cable to the lower part and charge fully, approx. 1 to 1.5 hours.



3 Fill the chamber

Place a lower screen in the ceramic chamber, add approx. 10 g of shisha tobacco loosely, do not press down.



4 Add the screen

Place an upper screen on top and wipe the chamber rim clean.



5 Insert

Place the chamber into the heating chamber with the screens facing up, screw the cap on firmly (do not overtighten).



6 Attach

Insert the silicone grommet (usually 18 mm, 16 mm if loose) into the base cap and press the device onto the bowl adapter until you feel resistance.



7 Set up

Switch on: press **O**, immediately press again and hold. 1× **O** duration, 1× **<** cap, 1× **>** side; start at 200 °C.



8 Preheat

2× **O**: approx. 8 minutes preheating, then “Enjoy your session”. 2× **O** extends by 10 minutes, up to 150 minutes maximum.

Important safety information

- The cap and heating chamber become very hot and stay hot for a long time. Do not touch; only remove the chamber when cool and with tweezers.
- Operate stable and upright on a heat-resistant surface, do not tilt, never unattended, out of the reach of children. For adults only.
- Not waterproof. Remove the battery before deep cleaning.
- Only use original ShishaX batteries and suitable USB-C power adapters; do not charge unattended.
- If you smell burnt plastic or metal, switch off immediately and stop using the device.

Buttons at a glance

What you want to do	How to do it
Switch on / off	press **O** once, then immediately press it again and hold until the display turns on or off
Set session duration	1× **O**, then adjust with **<** / **>**
Cap temperature (top)	1× **<**, then adjust with **<** / **>**
Side temperature	1× **>**, then adjust with **<** / **>**
Start preheating	2× **O** (double tap) on the home screen
Skip preheating	hold **O** for 2 seconds during preheating
Pause	1× **O** during the session
Resume	2× **O** after a pause
Extend session	2× **O** during the session: +10 minutes each, 150 minutes maximum in total
Set LED ring	3× **O**, then choose one of the 5 modes or “OFF” with **<** / **>**
Button lock on/off	4× **O** in quick succession
Device settings	**<** and **>** together; select with **<** / **>**, switch on or off with **O**

After the session

Switch off, let it cool for at least 30 minutes, unscrew the cap, remove the ceramic chamber with tweezers, remove screens and tobacco residue, brush out the heating chamber dry. Never rinse or immerse.

Detailed user manual
https://documents.hookain.de/manual/shishax/volta/en/shishax-volta-bedienungsanleitung-en-v2.pdf

App (optional): Android ShishaX app on Google Play; iPhone via the SHX Browser with shishax.app.

Manufacturer
ShishaX · SHX Corporation · 1602 Lockness Place · Torrance, CA 90501 · USA
Phone: +1 908 947 8590 · E-mail: sales@shishax.com · shishax.com · Support: support.shishax.com

Retailer
HOOKAIN GmbH · Grüner Brunnenweg 146 · 50827 Köln · Germany
Phone: +49 221 999 88 111 · E-mail: b2b@hookain-tobacco.com

Status: 27.09.2026, version 1. Information according to the manufacturer; illustrations may differ from the product. Tobacco is not included.